



Installation instructions **M. 2 SSD** in **SF8008 SUPREME** (hard disk not included)

What you need: M. 2 SSD (type: SSD - M KEY - PCIE NVME), screwdriver

Safety note: Please disconnect the receiver completely from the power supply before installing a hard disk!

1. Remove the three marked screws on the back (The warranty seal can only be removed without invalidating the warranty when installing a hard disk. Other modifications to the electronics are not permitted.)



2. Remove the red marked screw



3. Insert the M. 2 SSD at a 30-degree angle into the appropriate slot. Press the opposite side down and attach the hard drive with the previously removed spacer screw



4. Attach the housing cover with the previously removed housing screws
5. While the TV is running, press the blue button – Select “Hard Disk” – Select “Initialization (Format Hard Disk)”



Service OCTAGON Germany
Buentenaecker 2, D-79730 Murg
Tel: 0049-(0)7763-704484 / Fax: 0049-(0)7763-704483
E-Mail: info@octagon-germany.de
Internet: www.octagon-germany.eu / Support: www.octagon-forum.eu
WEEE-Reg.-Nr. DE 69966297